

PORTAIL BATTANT EN KIT

SWING GATE



INSTALLATION
INSTALLATION

Portail / Gate



Notice / Instructions






BOX 1/3		
N°	Section	QTY
1		2
2		2
22		2
9		1
19		1
10		4
11		2
12		2
13		8
14		2
15		1
16		1
17		16

BOX 1/3		
N°	Section	QTY
18		8
20		1
21		1
BOX 2/3		
N°	Section	QTY
5		1643.5H=20
		1788H=22

BOX 3/3		
N°	Section	QTY
31		2
32		2
33		1
34		2
35		1
36		1
37		1
38		3
40		12
41		2
42		1
43		2
44		1

1




N°	1	2	22	5	9	10	11	12	13	14
Section										
QTY	2	2	2	1643.5H=20 1788H=22	1	4	2	2	8	2



N°	15	16	17	18	19	20	21
Section							
QTY	1	1	16	8	1	1	1





2



3




[A]



[B]



4




[A]*1

[B]*1

N°	31	32	33	34	35	36	37
Section							
QTY	2	2	1	2	1	1	1



N°	38	40	41	42	43	44
Section						
QTY	3	12	2	1	2	1

5








6



7





N°	32	40
Section		
QTY	2	4






8

N°	A	B	31	40
Section				
QTY	1	1	2	4






9

N°	34	35	36	37	38	41	42	43	44
Section									
QTY	2	1	1	1	3	2	1	2	1





10



N°	33	40
Section		
QTY	1	4

