

PORTAIL BATTANT EN KIT

SWING GATE



INSTALLATION
INSTALLATION

Portail / Gate



Notice / instructions



V1- 02/2026




BOX 1/3		
N°	Section	QTY
1		1
2		2
3		1
4		2
6		40
7		2
8		2
9		4
10		2
11		1
12		1
14	 	16

BOX 1/3		
N°	Section	QTY
15	 	8
16		8
17		1
18		1
19		2

BOX 2/3		
N°	Section	QTY
5		22
14-27 14-28		4

BOX 3/3		
N°	Section	QTY
31		2
32		2
33		1
34		2
35		1
36		1
37		1
38		3
40		12
41		2
42		1
43		2
44		1

1






N°	1	2	3	4	5	6	7	8	9	10
						14-27 14-28				
Section										
QTY	1	2	1	2	22	40 4	2	2	4	2


N°	11	12	14	15	16	17	18	19
Section								
QTY	1	1	16	8	8	1	1	2




2





3



[A]




4



[B]



5




[A]*1

[B]*1

N°	31	32	33	34	35	36	37
Section							
QTY	2	2	1	2	1	1	1



N°	38	40	41	42	43	44
Section						
QTY	3	12	2	1	2	1

6








7



8





N°	32	40
Section		
QTY	2	4






9

N°	A	B	31	40
Section				
QTY	1	1	2	4






10

N°	34	35	36	37	38	41	42	43	44
Section									
QTY	2	1	1	1	3	2	1	2	1





11



N°	33	40
Section		
QTY	1	4

